

Make & Model	Type	Years	Bulk Quick Plug#	Pkg. Quick Plug#	Install Time	Harness Location
			New#	New#		
BUICK						
Enclave		08-16	51422	51423	5	BH1
CADILLAC						
Escalade		14-16	51451	51452	5	BH3
		03-06	51352	51353	5	BH3
		2002	51342	51343	5	BH3
CHEVROLET/GMC						
Acadia		07-16	51422	51423	5	BH1
Avalanche		03-06	51352	51353	5	BH3
		2002	51342	51343	5	BH3
		14-16	51451	51452	5	BH1
Silverado/Sierra	New Body	07-13	Truck is not equipped with a brake control harness. Hardwire #51515 to blunt cut wires under dash.			
	Classic Body	2007	51352	51353	5	BH3
		03-06	51352	51353	5	BH3
Tahoe		99-02	51342	51343	5	BH3
		15-16	51451	51452	5	BH3
		03-06	51352	51353	5	BH3
Suburban, Yukon Yukon XL & Denali	New Body w/Amber Turn Signals	00-02	51342	51343	5	BH3
		14-16	51451	51452	5	BH3
Yukon XL & Denali		03-06	51352	51353	5	BH3
	New Body w/Amber Turn Signals	00-02	51342	51343	5	BH3
Traverse	w/Factory Tow Package	09-16	51422	51423	5	BH3
CHRYSLER						
Aspen	w/Factory Tow Package	07-09	51332	51333	5	BH1
DODGE/RAM						
Dakota	w/Factory Tow Package	97-11	51332	51333	5	BH1
Durango	w/Factory Tow Package	11-15	51446	51447	5	BH8
		98-09	51332	51333	5	BH1
Ram 1500		15-16	51457	51458	10	BH2
		13-14	-	51453	10	BH8
		10-12	51438	51439	5	BH8
Ram 2500		15-16	51457	51458	10	BH2
		13-14	-	51453	10	BH8
		10-12	51438	51439	5	BH8
Ram 3500		15-16	51457	51458	10	BH2
		13-14	-	51453	10	BH8
		10-12	51438	51439	5	BH8
Ram Pickup	All Full Size Pickups	95-09	51332	51333	5	BH1
FORD						
Bronco	Full Size	94-96	51322	51323	5	BH2
		92-93	51312	51313	5	BH1
Econoline Van		09-14	51432	51433	5	BH5
		92-08	51322	51323	5	BH1
Excursion		00-05	51322	51323	5	BH2
Expedition		13-14	51432	51433	5	BH5
		97-12	51322	51323	5	BH2
Explorer	w/Factory Tow Package	02-16	51322	51323	5	BH2
F-150	New Body	04-08	51322	51323	5	BH2
	Heritage Edition	2004	51322	51323	5	BH2
F-150 & F-250 Light Duty		94-03	51322	51323	5	BH2
F-250 & F-350 Super Duty		08-16	51432	51433	5	BH5
		05-07	51372	51373	5	BH4
F-250 & F-350 Heavy Duty		99-04	51322	51323	5	BH2
		1997	51322	51323	5	BH2
F-150, F-250, F-350		94-96	51322	51323	5	BH2
F-Series Full Size Truck		92-93	51312	51313	5	BH1
F-450 & F-550 Super Duty		08-14	51432	51433	5	BH5
		05-07	51372	51373	5	BH4
Flex	w/Factory Tow Package	12-13	51436	51437	5	BH7
		09-11	51322	51323	5	BH2
Windstar	w/Factory Tow Package	95-03	51322	51323	5	BH2
HONDA						
Pilot		09-16	51392	51393	5	BH1
Ridgeline	w/Factory Tow Package	06-14	51392	51393	5	BH1
HUMMER						
H2		03-07	51352	51353	5	BH3
INFINITI						
QX56		04-13	51382	51383	5	BH1
JEEP						
Grand Cherokee	w/Factory Tow Package	11-15	51446	51447	5	BH8
KIA						
Borrego		09-11	51442	51443	5	BH1
LAND ROVER						
LR3		05-09	51322	51323	5	BH2
LR4		10-14	51322	51323	5	BH2
Range Rover	Including Sport	05-15	51322	51323	5	BH2
Range Rover Evoque		12-14	51322	51323	5	BH2
LEXUS						
GX460		10-12	51362	51363	5	BH1
GX470		03-11	51362	51363	5	BH1
LX470		03-07	51362	51363	5	BH1
LX570		2013	51362	51363	5	BH1
		08-11	51362	51363	5	BH1
LINCOLN						
Mark LT		06-08	51322	51323	5	BH2
MKT	w/Factory Tow Package	12-15	51436	51437	5	BH7
		10-11	51322	51323	5	BH2
Navigator		13-14	51432	51433	5	BH5
		98-12	51322	51323	5	BH2
MERCURY						
Mountaineer	w/Factory Tow Package	02-10	51322	51323	5	BH2
NISSAN						
Armada		04-15	51382	51383	5	BH1
Frontier		05-16	51382	51383	5	BH1
Pathfinder		05-15	51382	51383	5	BH1
Titan		04-15	51382	51383	5	BH1
Xterra		05-15	51382	51383	5	BH1
SATURN						
Outlook		07-09	51422	51423	5	BH1
TOYOTA						
4Runner		03-16	51362	51363	5	BH1
Land Cruiser		13-14	51362	51363	5	BH1
		03-11	51362	51363	5	BH1
Sequoia		03-14	51362	51363	5	BH1
Tacoma		2016	51455	51456	5	BH4
		07-15	51362	51363	5	BH1
Tundra		15-16	51455	51456	5	BH4
		03-14	51362	51363	5	BH1

Harness Location Designators:

- BH1 = Underneath dash, left of steering column, near emergency brake pedal
- BH2 = Underneath dash, near center console
- BH3 = Underneath dash, in junction box left of steering column
- BH4 = Behind storage pocket, above ashtray
- BH5 = Underneath dash, behind center access panel on passenger side
- BH6 = Underneath dash, near brake pedal
- BH7 = Behind storage pocket in center of dash
- BH8 = Underneath dash, to right of emergency brake pedal

Red text indicates products Continued While Supplies Last (CWSL).